

# Installation of the PowerMoni Spot




1. Locate the PowerMoni Spot ID on the unit. (As seen in red above).

Log in to ReMoni's online portal:  
[ReCalc.ReMoni.com](http://ReCalc.ReMoni.com) and register the unit.



2. The PowerMoni Spot reads its data from the point where the CE symbol is placed. See the picture above.

## For soft cable mounting



3a. Make sure you have everything in the picture.

- (1) PowerMoni Spot, 1 pcs.
- (2) Cable Fix, 1 pcs.
- (3) Cable ties, 4 pcs.



- 4a. Mount the PowerMoni Spot and the Cable Fix on the cable with the cable ties. Mount the PowerMoni Spot with a minimum distance of 10 cm from other cables, even further if it is thicker cables.

The PowerMoni Spot is now installed.

## For hard cable mounting



3b. Make sure you have everything in the picture.

- (1) PowerMoni Spot, 1 pcs.
- (2) Cable ties, 4 pcs.



- 4b. Mount the PowerMoni Spot on the cable with the cable ties. Mount the PowerMoni Spot with a minimum distance of 10 cm from other cables, even further if it is thicker cables.

The PowerMoni Spot is now installed.

Please note - ReMoni recommend to install the ReMoni gateway before the PowerMoni Spot.

After connecting the PowerMoni Spot, it can take up to 60 minutes before the measured values are visible on ReMoni's online portal [ReCalc.ReMoni.com](http://ReCalc.ReMoni.com). Datasheets can be found on ReMoni's website: [ReMoni.com](http://ReMoni.com).

Images are indicative and are subject to errors and changes.

Revised: April 2018