

## Installation of PowerMoniSpot

1. Log in to ReCalc: [recalc.remoni.com](http://recalc.remoni.com) and register a unit with the ID on the side of the sensor.




2. The PowerMoniSpot measures from the point where the CE symbol is placed, marked in the picture below.




3a. Installation on **soft** cable:

Mount the PowerMoniSpot and the cable fix on the cable with the cable ties. Mount the PowerMoniSpot with a minimum distance of 10 cm from other cables if they are  $\varnothing 40$  mm or thicker.




3b. Installation on **hard** cable:

Mount the PowerMoniSpot on the cable with the cable ties. Mount the PowerMoniSpot with a minimum distance of 10 cm from other cables if they are  $\varnothing 40$  mm or thicker.



4. Wrap the metal film around the sensor and the cable to isolate it from noise from other cables and electronics.



## Calibration of PowerMoniSpot

For instructions on calibration of PowerMoniSpot, visit our knowledge center at [remoni.com](http://remoni.com) and find the level of calibration you want in the FAQ.

Please note - ReMoni recommends installing the ReMoni Gateway before the sensor. After connecting the sensor, it can take up to 60 minutes before the measured values are visible in ReCalc: [recalc.remoni.com](http://recalc.remoni.com). Data sheets can be found on ReMoni's website: [remoni.com](http://remoni.com).